



WILDLIFE FEEDERS

SHORT AND LONG LEG FEED CONTAINER

INSTRUCTIONS

▲ WARNINGS: To prevent serious injury or death:

1. Assemble this feed container with the supplied hardware only.
2. Never put more than 200 pounds of feed in this feed container.
3. Never walk under any hanging feeder, support cable, or tripod.
4. Discontinue use if any part is excessively worn or broken.
5. Wear gloves to protect hands from sharp metal edges.
6. Check all hardware and support legs before each use.
7. Never lean a ladder against the feed container.

ASSEMBLY:

1. Locate the 24-gallon feed container, cover, three legs, and mounting hardware.
2. Remove the feed container cover and place it in a safe location.
3. Align the two holes in one of the support legs with two holes in the sides of the feed container.

IMPORTANT: The three legs must point down and away from the bottom of the feed container to form a support tripod when all three legs are attached.

4. Insert the bolts through the holes in the leg, then into the sides of the feed container.
5. Reach inside the feed container, and place a flat washer then a lock nut onto each bolt. Tighten the lock nuts by hand. Repeat for the remaining two legs.
6. Using the proper tools, tighten the six (6) locknuts onto each of the six bolts equally until the three legs are fastened securely to the feed container.
7. Mount any of the Spinpro feeders to this feed container with the instructions included with the feeder.
8. Move the feed container to your chosen location, and then fill the container with the desired feed. (200 pounds maximum) Replace the cover.

WARNING: To prevent serious injury or death, NEVER lean a ladder against the feed container to the fill feed container or work on the feeder.